# **AMPM**

### Chandelier Installation and Dismantle Directions

### **Parts in Case**

- 15-ft. white extension cord
- Transformer box and connection wire
- Six smoked acrylic chandelier wings
- Red acrylic tube w/light, wire and two white connector poles
- Airline cable and crimps



## **AMPM**

#### **Directions for Installation**

1. Connect the two white pipes to the main light structure.



- 2. Connect the airline cable to the light and then connect it to the display.
- 3. Once the main structure is secured, put the smoked acrylic chandelier wings on (slide in position). Must connect opposite sides as you install them.



- 4. Connect the top of the wire that extrudes from the white poles to the transformer.
- 5. Tape the transformer to the top of the truss.

## **AMPM**

- 6. Run the wire from the transformer towards the closet on the top of the closet. Plug in the white extension cord to the end of the black wire from the transformer.
- 7. Test the light.

#### **Directions for Dismantle**

- 1. Unplug the extension cord and roll it up so it fits in the case.
- 2. Remove the tape from the transformer and black cord and place the transformer and black cord into the case.
- 3. Carefully, remove the acrylic chandelier wings one at a time and opposite sides at a time to keep the unit's weight distribution even.
- 4. Wrap each acrylic wing into a protective wrap and place into the case.
- 5. Remove the airline cable from the display, but leave the cable connected to the top of the light unit.
- 6. Unscrew and disconnect the two white posts from the main chandelier unit; keeping the wire threaded through the white posts.
- 7. Wrap the red acrylic light.
- 8. Put the main unit with the red light and white posts into the case.